



PG-103-106-AA BACnet IP to JCI Metasys N2 Protocol Converter

PG-103-106-AA is highly powerful, superior, completely configurable and productive Building & Industrial Automation gateway for integrators to effortlessly interface devices to networks in commercial buildings and industrial plants.

PG-103-106-AA Gateway model supports BACnet IP and JCI Metasys N2 protocols. It is a Bi-directional Converter that can be configured as a Client and/or a Server on either protocol interface.

When configured as a JCI Metasys N2 client, the PG-103-106-AA can read data from your JCI Metasys N2 devices and publish it as BACnet IP data. Also, it can write commands sent from the BACnet IP side to the JCI Metasys N2 devices.

When configured as a BACnet IP client, the PG-103-106-AA can read data from your BACnet IP devices and publish it as JCI Metasys N2 data. Also, it can write commands sent from the JCI Metasys N2 side to the BACnet IP devices.

The PG-103-106-AA can be configured to behave as a server on both JCI Metasys N2 and BACnet IP interfaces. This mode is useful when data exchange is required between a JCI Metasys N2 client (for eg. SCADA) and a BACnet IP client (for eg. a Building Management System).

The PG-103-106-AA can be configured to behave as a client on both JCI Metasys N2 and BACnet IP interfaces.

PG-103-106-AA gateways have benefitted system integrators worldwide with its powerful line of gateways. Additionally, PG-103-106-AA gateway runs the same protocol conversion software on a productive and cost efficient platform backed by the experience, engineering expertise and technically proven support that integrators have come to expect from PG-103-106-AA.

Features

- Ability to interface upto 1000 points
- DIN rail mount optional
- DIP switches to select baud rate or node ID on the fly
- Multi-configuration capability
- BACnet COV support for fast data communication while reducing the traffic over a BACnet network

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



Specifications

Environment	Operating Temperature: -40 to 75° C (-40 to 167°F)	
	Relative Humidity:5-90% RH non-condensing	
Power Requirements	9-30 VDC or 12-24 VAC	
	Current Draw @ 12V about 250mA	
Physical Dimensions(HxWxD)	4.5x2.9x1.6 in. (11.5x7.4x4.1 cm)	
	0.4 lbs (0.2 Kg)	
Other	Configuration/Diagnostic utilities	
	Capacity: 1000 points	
	Table,Wall or DIN rail mount	
Communication Interfaces	RS-485	2
	RS-232	-
	Ethernet 10Base-T, 100BASE-T ²	1
	Mbus	-
	KNX	-
	LonWorks	-
Approvals	TUV Approved to UL 916 and CSA C22.2 standards	
	BTL and LonMark certified	
	LonMark Certified	
	RoHS Compliant	
	GOST-R Certified	
	CE and FCC	

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



BACnet IP Protocol Driver Description

Driver Name: BACnet/IP	Connection type:	Internet Protocol (IP)
	Ethernet Speeds Supported:	10Base-T, 100BASE-T ²
	BBMD SUPPORTED:	Yes(Not supported on client connections)
	Foreign Device:	Not Supported for client
	Registration:	Connections
PG-103-106-AA AS A BACnet IP CLIENT		
Read Operations Supported	Properties Supported	Comments and Limitations
Read Property	Present Value	Store value in Data Array location after scaling has been applied
	Out_Of_Service	When using a Complex Data Object, the OOS property is fully supported. Return FALSE when not OOS or when using standard Data Arrays
	Units	Returns Units as specified in the Map Descriptor
	Reliability	When using a Complex Data Objects, returns "Unreliable Other" when the Node is offline, or when the data is old. Returns FALSE if the Node is online or when using Standard Data Arrays
	Priority_Array	Returns Priority_Array of Map Descriptor
	Unsupported	This property is supported
	Protocol_Object_Type_Supported	This property is supported
	Protocol_Services_Supported	This property is supported
	Database_Revision	This property is supported and will change if a new configuration is downloaded to the FS
	Max_Master	This property is supported for the BACnet /MSTP DLL option
	Max_Info_Frames	This property is supported for the BACnet/MSTP DLL option
	Relinquish_Default	Returns Relinquish_Default
Read Property Multiple	As for Read Property	Transactions can be defined to read multiple objects and properties in a single

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



		ReadPropertyMultiple operation.
	ALL	Read Property Multiple of the ALL property is NOT supported
Write Operations Supported	Properties Supported	Comments and Limitations
Write Property	Present Value	Send value in Data Array location after scaling has been applied
Write Property Multiple		
PG-103-106-AA AS A BACnet IP SERVER		
DEVICE OBJECT		
Read Operations Supported	Properties Supported	Comments and Limitations
Read Property	Object_Identifier	Returns Object_ID with Node_ID as Object Instance
	Object_Name	Returns Node Name
	Object_Type	Returns Device Object type
	System_Status	Returns Normal
	Vendor_Name	Returns PG-10XX Technologies
	Vendor_Identifier	Returns 37
	Model_Name	Returns PG-10XX model
	Firmware_revision	Returns Kernel Version
	Application_sw_version	Returns DCC version
	Protocol_Version	Returns version 1
	Protocol_Revision	Returns version 1
	Protocol_Services_Supported	This property is supported
	Protocol_Object_Type_Supported	This property is supported
	Protocol_Object_List	Returns a list of objects defined in the PG-10XX
	Max_APDU_Length_Accepted	For PG-10XX,the MAX APDU length for BACnet MSTP is 480 bytes and for BACnet IP/BACnet Eth 1497 bytes
	Segmentation_Supported	Returns Segmantation NOT Supported
	APDU_Timeout	Returns the value as defined by the Node’s “Timeout” paramater
	APDU_Retries	Returns the value as defined by the Node’s “Retries” parameter
	Device_Address_Bindings	Returns an empty list
	Max_Master	This property is supported for the BACnet/MSTP DLL option



	Max_info_Frames	This property is supported for the BACnet/MSTP DLL option
	Description	This property is supported
	Database_Revision	This property is supported and will change if a new configuration is downloaded to the PG-10XX
Read Property Multiple	Same properties as Read Property	Read Property Multiple is fully supported. Multiple objects with multiple properties can be specified
Write Operations Supported	Properties Supported	Comments and Limitation
Write Property	Max_Master	This Property is supported for the BACnet /MSTP DLL option
	Max_info_Frames	This Property is supported for the BACnet /MSTP DLL option
Write Property Multiple	Max_Master	This Property is supported for the BACnet /MSTP DLL option
	Max_info_Frames	This Property is supported for the BACnet /MSTP DLL option
Analog Input Object		
Read Operations Supported	Properties Supported	Comments and Limitations
Read Property	Object_Identifier	No Limitations
	Object_Name	Returns Map Descriptor Name
	Object_Type	Returns Analog Input Object Type
	Present_Value	Returns value in Data_Array after scaling has been applied
	Status_Flags	When using Complex Data Objects returns the FAULT and OUT_OF_SERVICE fields as indicated in section 12.2.7 of the BACnet specification. When using standard Data Arrays returns FALSE for all bits.
	Event_State	No Limitations
	Reliability	When using a Complex Data Objects, returns Unreliable Other when the Node is offline, or when the data is old. Returns FALSE if the node is online or when using Standard

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



		Data Arrays
	Out_Of_Service	Fully supported when using a Complex data Object. Returns FALSE when not OOS or when using standard Data Arrays
	Description	This property is supported
	Units	Returns Units as specified in the Map Descriptor
Read Property Multiple	Same properties as Read Property	Read Property Multiple is fully supported. Multiple objects with Multiple properties can be specified
Write Operations Supported	Properties Supported	Comments and Limitations
Write Property	Present_Value	Writing to the Present Value is allowed if the Object is OOS
Write Property Multiple		
Data Sharing Operations Supported	Properties Supported	Comments and Limitations
SubscribeCOV	Present_value	Subscription storage is non-volatile
COVNotification	Present_value	Confirmed and Unconfirmed
Alarm and Event Operations Supported	Properties Supported	Comments and Limitations
EventNotification	Present_Value,Status	Confirmed and Unconfirmed
AcknowledgeAlarm		No limitations
Analog Output Object, Analog Value Object		
Read Operations Supported	Properties Supported	Comments and Limitations
Read Property	Object_Identifier	No Limitations
	Object_Name	Returns “Map Descriptor Name”
	Object_Type	Returns Analog Output Object type
	Present_Value	Returns value in Data Array after scaling has been applied
	Status_Flags	When using Complex Data Objects returns the FAULT and OUT_OF_SERVICE fields as indicated in section 12.2.7 of the BACnet specification. When using standard Data

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



		Arrays returns FALSE for all bits
	Event_State	No Limitations
	Reliability	When using a Complex Data Objects, returns “Unreliable Other” when the Node is offline, or when the data is old. Returns FALSE if the Node is online or when using Standard Data Arrays
	Out_Of_Service	Fully supported when using a Complex Data Object. Returns FALSE when not OOS or when using standard Data Arrays
	Units	Returns Units as specified in the Map Descriptor
	Priority_Array	Returns Priority_Array of Map Descriptor
	Description	This property is supported
	Relinguish_Default	Returns Relinguish_Default
Read Property Multiple	Same properties as Read Property	Read Property Multiple is fully supported. Multiple objects with multiple properties can be specified
Write Operations Supported	Properties Supported	Comments and Limitations
Write Property	Present_Value	When using Complex Data Objects and OOS is TRUE, then the write will not cause a write-through operation to the Server side. If the OOS is FALSE or when using standard Data Arrays then writes will always cause a write-through operation to the Server side
Write Property Multiple		
Data Sharing Operations Supported	Properties Supported	Comments and Limitations
SubscribeCOV	Present_Value	Subscription storage is non-volatile
COVNotification	Present_Value	Confirmed and Unconfirmed
Alarm and Event Operations Supported	Properties Supported	Comments and Limitations
Event Notification	Present_Value, Status	Confirmed and Unconfirmed
AcknowledgeAlarm		No Limitations

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



Binary Input Object		
Read Operations Supported	Properties Supported	Comments and Limitations
Read Property	Object_Identifier	No Limitations
	Object_Name	Returns "Map Descriptor Name"
	Object_Type	Returns Analog Input Object type
	Present_Value	Returns the binary value in the data array
	Status_Flags	When using Complex Data Objects returns the FAULT and OUT_OF_SERVICE fields as indicated in section 12.2.7 of the BACnet specification. When using standard Data Arrays returns FALSE for all bits
	Event_State	No Limitations
	Reliability	When using a Complex Data Objects, returns "Unreliable Other" when the Node is offline, or when the data is old. Returns FALSE if the Node is online or when using Standard Data Arrays
	Out_Of_Service	Fully supported when using Complex Data Object. Returns FALSE when not OOS or when using standard Data Arrays
	Polarity	Always returns "Normal"
	Active_Text	Returns Active Text as specified on the Map Descriptor
	Description	This property is supported
	Inactive_Text	Returns Inactive Text as specified on the Map Descriptor
Read Property Multiple	Same properties as Read Property	Read property Multiple is fully supported. Multiple objects with multiple properties can be specified
Write Operations Supported	Properties Supported	Comments and Limitations
Write Property	Present_Value	Writing to the Present Value is allowed if the Object is OOS
Write Property Multiple		

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



Data Sharing Operations Supported	Properties Supported	Comments and Limitations
SubscribeCOV	Present_Value	Subscription storage is non-volatile
COVNotification	Present_Value	Confirmed and Unconfirmed
Alarm and Event Operations Supported	Properties Supported	Comments and Limitations
Event Notification	Present_Value, Status	Confirmed and Unconfirmed
AcknowledgeAlarm		No Limitations
Binary Output Object, Binary Value Object		
Read Operations Supported	Properties Supported	Comments and Limitations
Read Property	Object_Identifier	No Limitations
	Object_Name	Returns "Map Descriptor Name"
	Object_Type	Returns Analog Input Object type
	Present_Value	Returns the binary value in the data array
	Status_Flags	When using Complex Data Objects returns the FAULT and OUT_OF_SERVICE fields as indicated in section 12.2.7 of the BACnet specification. When using standard Data Arrays returns FALSE for all bits
	Event_State	No Limitations
	Reliability	When using a Complex Data Objects, returns "Unreliable Other" when the Node is offline, or when the data is old. Returns FALSE if the Node is online or when using Standard Data Arrays
	Out_Of_Service	Fully supported when using Complex Data Object. Returns FALSE when not OOS or when using standard Data Arrays
	Priority_Array	Returns Priority_Array of Map Descriptor
	Relinquish_Default	Returns Current

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



		Relinguish_Default
	Description	This property is supported
	Active_Text	Returns Active Text as specified on the Map Descriptor
	Inactive_Text	Returns Inactive Text as specified on the Map Descriptor
Read Property Multiple	Same properties as Read Property	Read property Multiple is fully supported. Multiple objects with multiple properties can be specified
Write Operations Supported	Properties Supported	Comments and Limitations
Write Property	Present_Value	When using Complex Data Objects and OOS is TRUE, then the write will not cause a write-through operation to the downstream side. If the OOS is FALSE or when using standard Data Arrays when writes will always cause a write-through operation to the downstream side
Write Property Multiple		
Data Sharing Operations Supported	Properties Supported	Comments and Limitations
SubscribeCOV	Present_Value	Subscription storage is non-volatile
COVNotification	Present_Value	Confirmed and Unconfirmed
Alarm and Event Operations Supported	Properties Supported	Comments and Limitations
Event Notification	Present_Value, Status	Confirmed and Unconfirmed
AcknowledgeAlarm		No Limitations
Multiple State Input Object		
Read Operations Supported	Properties Supported	Comments and Limitations
Read Property	Object_Identifier	No Limitations
	Object_Name	Returns “Map Descriptor Name”
	Object_Type	Returns Analog Input Object type



	Present_Value	Returns unsigned Integer value in the data array
	Status_Flags	When using Complex Data Objects returns the FAULT and OUT_OF_SERVICE fields as indicated in section 12.2.7 of the BACnet specification. When using standard Data Arrays returns FALSE for all bits
	Event_State	No Limitations
	Reliability	When using a Complex Data Objects, returns “Unreliable Other” when the Node is offline, or when the data is old. Returns FALSE if the Node is online or when using Standard Data Arrays
	Description	This property is supported
	Out_Of_Service	When using a Complex Data Object, the OOS property is fully supported. Returns FALSE when not OOS or when using standard Data Arrays
	Number_Of_State	When using a Complex Data Object, returns the number of states defined. When using Standard Data Arrays returns the value of 5
	State_Text	When using Complex Data Objects returns the State Text Strings defined. When using Standard Data Arrays return “State_X” where “X” is the value stored in Data_Array and could be 0 to 4
Read Property Multiple	Same properties as Read Property	Read property Multiple is fully supported. Multiple objects with multiple properties can be specified
Write Operations Supported	Properties Supported	Comments and Limitations
Write Property	Present_Value	Writing to the Present Value is allowed if the Object is OOS
Write Property Multiple		
Data Sharing Operations	Properties Supported	Comments and Limitations

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



Supported		
SubscribeCOV	Present_Value	Subscription storage is non-volatile
COVNotification	Present_Value	Confirmed and Unconfirmed
Alarm and Event Operations Supported	Properties Supported	Comments and Limitations
Event Notification	Present_Value, Status	Confirmed and Unconfirmed
AcknowledgeAlarm		No Limitations
Multi-State Output Object, Multi-State Value Object		
Read Operations Supported	Properties Supported	Comments and Limitations
Read Property	Object_Identifier	No Limitations
	Object_Name	Returns "Map Descriptor Name"
	Object_Type	Returns Analog Input Object type
	Present_Value	Returns unsigned Integer value in the data array
	Status_Flags	When using Complex Data Objects returns the FAULT and OUT_OF_SERVICE fields as indicated in section 12.2.7 of the BACnet specification. When using standard Data Arrays returns FALSE for all bits
	Event_State	No Limitations
	Reliability	When using a Complex Data Objects, returns "Unreliable Other" when the Node is offline, or when the data is old. Returns FALSE if the Node is online or when using Standard Data Arrays
	Out_Of_Service	Fully supported when using a Complex Data Object. Returns FALSE when not OOS or when using standard Data Arrays
	Number_Of_State	When using a Complex Data Object, returns the number of states defined. When using Standard Data Arrays returns the value of 5
	State_Text	When using Complex Data Objects returns the State Text Strings defined. When using Standard Data Arrays return

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



		“State_X” where “X” is the value stored in Data_Array and could be 0 to 4
	Description	This property is supported
	Priority_Array	Returns Priority_Array of Map Descriptor
	Relinguish_Default	Returns Relinguish_Default
Read Property Multiple	Same properties as Read Property	Read property Multiple is fully supported. Multiple objects with multiple properties can be specified
Write Operations Supported	Properties Supported	Comments and Limitations
Write Property	Present_Value	When using Complex Data Objects and OOS is FALSE or when using standard data arrays, writes will trigger a write through operation to client side
Write Property Multiple		
Data Sharing Operations Supported	Properties Supported	Comments and Limitations
SubscribeCOV	Present_Value	Subscription storage is non-volatile
COVNotification	Present_Value	Confirmed and Unconfirmed
Alarm and Event Operations Supported	Properties Supported	Comments and Limitations
Event Notification	Present_Value, Status	Confirmed and Unconfirmed
AcknowledgeAlarm		No Limitations
Notification Class Object		
Read Operations Supported	Properties Supported	Comments and Limitations
Read Property	Object_Identifier	No Limitations
	Object_Name	Returns “Map Descriptor Name”
	Object_Type	Returns Notification Class Object type
	Description	No Limitations
	Notification_Class	No Limitations
	Priority	No Limitations
	Ack_Required	No Limitations
	Description	This Property is supported
	Recipient List	No Limitations

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



Read Property Multiple	Same properties as Read Property	Read property Multiple is fully supported. Multiple objects with multiple properties can be specified
Write Operations Supported	Properties Supported	Comments and Limitations
Write Property	Recipient_List	RecipientList storage is non-volatile
Write Property Multiple		
AddList	RecipientList	Used to subscribe to Alarm and Event Notifications
Unsupported Functions And Data Types		
BACnet Object Type not Supported		
Averaging Object		
Calendar Object		
Command Object		
Event Enrollment Object		
File Object		
Group Object		
Life Safety Point Object		
Life Safety Zone Object		
Loop Object		
Notification Class Object unsupported on Client side only		
Program Object		
Schedule Object		
BACnet Services not Supported		
Alarm and Event Services unsupported on Client side only		
File Access Services		
Virtual Terminal Services		
COV and EventNotification services are not supported for BACnet		
MSTP on the ProtoCessor		
For BACnet MSTP , PTP and Arcnet , COV services are disabled by default and may be enabled by setting the Node_Option property to COV_Enable in the Nodes section configuration file.		

JCI Metasys N2 Protocol Driver Description

PG-103-106-AA Mode	Comments
Client	Nodes: 1 Only 1 client node allowed on Multidrop systems. Can communicate with: - N2Open

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



	- VMA 1400 series (AI, BI, AO, BO and custom types) -DX9100/XT9100
Server	Nodes: 255
Formal Driver Type	Serial
	Client
	Server
Connection Information	
Connection type:	RS-485 (Two-wire, Half Duplex)
Baud Rates:	9600 (N2 Standard)
Data Bits:	8
Stop Bits:	1
Parity:	None
Multidrop Capability:	Yes
N2Open Functions:	
Data Type Supported	
PG-103-106-AA Data Type	Description
Analog_Input	Analog Input (AI)
Digital_Input	Binary Input (BI)
Analog_Output	Analog Output (AO)
Digital_Output	Binary Output (BO)
Float_Reg	Internal Float value (ADF)
Integer	Internal Integer value (ADI)
Byte	Internal Byte value (BD)
Read Operations Supported	
PG-103-106-AA As a Client	PG-103-106-AA As a Server
Read Current Value (all data types) direct read, Change-of –State (COS) poll	Read Current Value (all data types) direct read, Change-of –State (COS) poll
Read Attribute (all data types): direct read, specifying a legal attribute number	Read Attribute (all data types): direct read, specifying a legal attribute number
Identify Self Command	Identify Self Command
Read All Attributes (Optional): These commands are used to read all attributes of specified (Analog Input, Binary Input, Analog Output, Binary Output) object without specifying attribute number.	Read All Attributes (Optional): These commands are used to read all attributes of specified (Analog Input, Binary Input, Analog Output, Binary Output) object without specifying attribute number.
Write (Control) Operations Supported	
PG-103-106-AA As a Client 2	PG-103-106-AA As a Server 2
Override Current Value (All data types) implemented as Write on PG-103-106-AA	Override Current Value (All data types) implemented as Write on PG-103-106-AA
Override Release (all data types)	Override Release (all data types)
Write Attribute (all data types) direct write,	Write Attribute (all data types) direct write,

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



specifying a legal attribute number	specifying a legal attribute number
Write characterize Attributes (Optional). These commands are used to set all attributes that characterize the specified (Analog Input, Binary Input, Analog Output or Binary Output) object without specifying an attribute number.	Write characterize Attributes (Optional). These commands are used to set all attributes that characterize the specified (Analog Input, Binary Input, Analog Output or Binary Output) object without specifying an attribute number.
Write Internal Parameter Command (Optional). This command is used to change the value attribute of internal parameter objects without specifying an attribute number.	Write Internal Parameter Command (Optional). This command is used to change the value attribute of internal parameter objects without specifying an attribute number.
Unsupported Functions and Data Types	
Function	Reason
Read Memory	Not Required
Diagnostics	
Warm Start	Not Required
Message	
Status Update	Not Required
Message	
Programming messages (download, upload)	Not Required PG-103-106-AA is a data transfer device)
Time Synch Not supported	Time Synch PG-103-106-AA clocks are updated on receipt of this command.
VMA Functions:	
Data Types Supported	
PG-103-106-AA Data Type	Description
Analog_Input	Analog Input (AI)
Digital_Input	Binary Input (BI)
Analog_Output	Analog Output (AO)
Digital_Output	Binary Output (BO)
Float_Reg	Internal Float value (ADF)
Integer	Internal Integer value (ADI)
Byte	Internal Byte value (BD)
Read Operations Supported	
PG-103-106-AA As a Client	PG-103-106-AA As a Server
Read Current value (all data types)	Not Applicable
Direct Read, Change-of-State (COS) poll	
Write (Control) Operations Supported	
PG-103-106-AA As a Client	PG-103-106-AA As a Server
Write/Override Current value (all data types) implemented as Write on PG-103-	Not Applicable

Protoconvert, 9/1484 Malvern Road, Glen Iris VIC 3146 Phone: +61-432-242-992

Email: sales.aus@protoconvert.com Website: protoconvert.com.au



106-AA	
Override Release (AI and BI only) uses writes for outputs and internal values	
Unsupported Functions and Data Types	
Function	Reason
Programming messages(upload,download)	Not required – PG-103-106-AA is a data transfer device
DX9100 Functions:	
Data Types Supported	
PG-103-106-AA Data Type	Description
	Supported sections of Address Map:
	General control module
	Programmable modules 1-12
	Analog input modules 1-8
	Analog output modules 1-2
	Digital output modules 3-8
	Extension modules 1-8
	Time schedules 1-8
	Optimal start/stop modules 1-2
	Analog output modules 9-10
	Auxiliary analog output modules 11-13
Read Operations Supported	
PG-103-106-AA As a Client	PG-103-106-AA As a Server
Read of all points supported	Not Applicable
Write (Control) Operations Supported	
PG-103-106-AA As a Client	PG-103-106-AA As a Server
Write of all points supported	Not Applicable
DX9100 may not allow writes to specific values	
Unsupported Functions and Data Types	
Function	Reason
Programming messages	Not required – PG-103-106-AA is a data transfer device

